



Notes: Assemble to avoid lead inductance.
 Idiode loop will radiate substantially
 if not kept short. Put output ceramic
 close by to eat up switching noise!
 Scope both output and drain to verify
 noise is not excessive.

EmarhaviI SSTC mk.II	
PFC power board	
Joshua Wise	2012/01/15